


# PIX-200 Full Power Reserve Battery Installation Manual

◆ **Unpack the battery kit and ensure that all accessories below are included.**

- 1 Battery Pack/ 1 Installation Manual (This Sheet)/ 1 Fastening Screw

◆ **HOW TO INSTALL THE BATTERY**


1. Unplug PIX-200 from the outlet.
2. Turn the unit upside down and open the battery cover.



3. Plug the battery cable into the connector to install the battery. Please make sure the dent side of the cable is facing up.

Battery Cable


Dent side up



4. After plugging the cable, place the battery inside and put the cover back in place.

5. Tighten the screw to secure the cover.

Screw Hole



**【Precautions】**

- ◆ Disable the print button before installing the battery. (Turning the unit upside down may push the print button and cause the unit to imprint after the battery is installed)
- ◆ After installing the battery, please charge the battery for 15 hours. When fully charged, full power reserve keeps the unit operational for 72 hours or 400 punches.  
PIX-200 exclusive full power reserve battery shall be used. Using other batteries may
- ◆ damage the unit. It is possible that it may become the cause of fire, injury or defacement by liquid spill, bursting or becoming hot.
- ◆ Do not remodel or touch the unit with wet hands. Doing so may cause fire or electric shock.